



SERIES	CONTROL IMAGE	BRAND	COMPONENT PN	ADDER OR LED PN	DESCRIPTION	REMOTE	ICON
TTV/TTF		HYNALL	RC-HYNALL-HNS131PIR-DH	-OCC	Passive infrared and daylight harvesting occupancy sensor	IR12	
		HYNALL	RC-HYNALL-HNB131CTL	-BT	Silvair Ready - control node (Bluetooth only)	NA	
		HYNALL	RC-HYNALL-HNB131PIR	-OCCBT	Silvair Ready - passive infrared and daylight harvesting occupancy sensor	NA	
TV/TF		HYNALL	RC-OCC-HNS134PIR	-OCC	Passive infrared and daylight harvesting occupancy sensor	IR12	
		HYNALL	RC-OCCBT-HNB134PIR	-OCCBT	Silvair Ready - passive infrared and daylight harvesting occupancy sensor	IR12	
TRV/TRF		HYNALL	RC-OCC-HNS134PIR	-OCC	Passive infrared and daylight harvesting occupancy sensor	IR12	
		HYNALL	RC-OCCBT-HNB134PIR	-OCCBT	Silvair Ready - passive infrared and day light harvesting occupancy sensor	IR12	
LBI		REMPHOS	RP-LBI-OC2-A	RP-LBI-OC2-A	LBI in-line microwave occupancy sensor	IR11	
		REMPHOS	RP-LBI-PIR-A	RP-LBI-PIR-A	LBI In-line passive infrared occupancy sensor	IR11	
		REMPHOS	RP-LBI-BLE-OC	RP-LBI-BLE-OC	LBI in-line Silvair microwave occupancy sensor	NA	
		REMPHOS	RP-LBI-BLE-A	RP-LBI-BLE-A	LBI in-line Silvair Bluetooth node	NA	
		REMPHOS	RP-LBI-BLE-PIR-A	RP-LBI-BLE-PIR-A	LBI in-line Silvair Bluetooth node with passive infrared occupancy sensor	NA	
LBI65		REMPHOS	RP-LBI65-PIR-A	RP-LBI65-PIR-A	LBI65 in-line passive infrared occupancy sensor	IR11	
		REMPHOS	RP-LBI65-BLE-PIR-A	RP-LBI65-BLE-PIR-A	LBI65 in-line Silvair Bluetooth node with passive infrared occupancy sensor	NA	
LBIMAX		HYNALL	RC-HYNALL-HNS111-A	-OCC	Microwave occupancy sensor	IR12	
		SHARKWARD	RC-SHARK-MW-7-BLE-SR	-OCBT	Silvair microwave occupancy sensor	IR12	
		HYNALL	RC-HYNALL-HNB136	-BT	Silvair Bluetooth node with external antenna	NA	
LS STRIP		HYNALL	RC-HYNALL-HNS-111-A	-OCC	Microwave occupancy sensor	IR12	
		SHARKWARD	RC-SHARK-MW-7-BLE-SR	-OCBT	Silvair microwave occupancy sensor	IR12	
		HYNALL	RC-HYNALL-HNB136	-BT	Silvair Bluetooth node with external antenna	NA	
LIVC		HYNALL	RC-HYNALL-HNS111-A	-OCC	Microwave occupancy Sensor	IR12	
		SHARKWARD	RC-SHARK-MW-7-BLE-SR	-OCBT	Silvair microwave occupancy Sensor	IR12	
		HYNALL	RC-HYNALL-HNB136	-BT	Silvair BT node with external antenna.	NA	
LBE		HYNALL	RC-HYNALL-HNS111-A	RC-OCC-HNS111-A	In line microwave occupancy sensor	IR12	
		HYNALL	RC-HYNALL-HNS111LR-A	RC-OCLR-HNS111LR-A	Limited range microwave occupancy sensor - no feet	NA	
		SHARKWARD	RC-SHARK-MW-7-BLE-SR	RC-OMWBT-MW-7-BLE-SR	Silvair Microwave occupancy sensor	IR12	
		HYNALL	RC-HYNALL-HNB131PIR	RC-OCCBT-HNB131PIR	Silvair Ready - passive infrared and day light harvesting occupancy sensor external mount only	NA	
		HYNALL	RC-HYNALL-HNB131CTL	RC-BT-HNB131CTL	Silvair Bluetooth node	NA	
		HYNALL	RC-Z10-ARM-HNB178-PIR-BLE	RC-OCCBT-ARM-HNB178-PIR-BLE	External z10 Port with PIR NLC	NA	
		HYNALL	RC-HYNALL-HNB136	RC-BTX-HNB136	Silvair Bluetooth node with external antenna	NA	



SIMPLE OCC SENSOR



NLC OCCUPANCY SENSOR



NLC NODE



SERIES	CONTROL IMAGE	BRAND	COMPONENT PN	ADDER OR LED PN	DESCRIPTION	REMOTE	ICON
		HYNALL	RC-HYNALL-HNS111-A_NF	-OC1	Microwave occupancy sensor - no feet	IR12	
		HYNALL	RC-HYNALL-HNS111LR-A	-OCLR	Limited range microwave occupancy sensor - no feet	IR12	
		SHARKWARD	RC-SHARK-MW-7-BLE-SR	-OCBT	Silvair microwave occupancy sensor	IR12	
		HYNALL	RC-HYNALL-HNB131CTL	-BT	Silvair Bluetooth node	NA	
		HYNALL	RC-HYNALL-HNB136	-BTX	Silvair Bluetooth node with external antenna	NA	
		HYNALL	RC-HYNALL-HNS111-A_NF	-OC1	Microwave occupancy sensor - no feet	IR12	
		HYNALL	RC-HYNALL-HNS111LR-A	-OCLR	Limited range microwave occupancy sensor - no feet	IR12	
		SHARKWARD	RC-SHARK-MW-7-BLE-SR	-OCBT	Silvair Microwave occupancy sensor	IR12	
		HYNALL	RC-HYNALL-HNB131CTL	-BT	Silvair Bluetooth node	NA	
		HYNALL	RC-HYNALL-HNB136	-BTX	Silvair Bluetooth node with external antenna	NA	



SIMPLE OCC SENSOR



NLC OCCUPANCY SENSOR



NLC NODE

REMOTES

SERIES	COMPONENT PN	LED PN	COMPATIBILITY
IR11 	RC-OC2-REMOTE-IR11	RC-REMOTE-IR11	LBI-OC2, LBI65 PIR Remote
IR12 	RC-HYNALL-REMOTE-IR12	RC-REMOTE-IR12	HNS111- LS, LBIMAX, LIVC, CR/SR

EXTERNAL LOAD CONTROLS, SWITCHES, AND SENSORS

PICTURE	BRAND	LED PN	DESCRIPTION
FIXTURE MOUNTED CONTROLS			
	SHARKWARD	RP-BRI819P-B-D-BLE	Silvair ready Bluetooth PIR Dimming Occupancy Sensor,BRI819P-B-D-BLE Standard, 120-277VAC
	SHARKWARD	RP-BRI819P-B-D-P-BLE	IP65 Silvair ready Bluetooth PIR Dimming Occupancy Sensor,BRI819P-B-D-BLE Standard, 120-277VAC
	MCWONG	RP-PSC-BL-I-FM-110-BLE-SR	Passive Infrared Bi-level Dimming Occupancy Sensor, Line Voltage, TruBlu™
	MCWONG	RP-PSC-WCM-450-BLE-SR	TruBlu SIG Mesh Room Controller, 120-277 Volt with dimming, 12 volt Aux, Sensor input, 20A Relay
DIMMERS AND WALL SENSORS			
	MCWONG	RP-PSC-DM-WS-100-BLE-SR	TruBlu SIG Mesh Dimming Wall Switch, 120-277V
	MCWONG	RP-PSC-DM-I-WS-100-BLE-SR	TruBlu SIG Mesh Dimming Wall Sensor Switch, 120-277V
	MCWONG	RP-PSC-EO-WS-100-BLE	Batteryless EnOcean Swtich, Single Rocker
	MCWONG	RP-PSC-EO-WS-400-BLE	Batteryless EnOcean Swtich, Double Rockers
	ENOCEAN	RP-ENOCEAN-ESRPB-W-EO	Easyfit Single Rocker Pad for EnOcean Radio
	ENOCEAN	RP-EDRPB-W-EO	Easyfit Double Rocker Pad for EnOcean Radio